

Technical Data Sheet

Elements	Volume
<ul style="list-style-type: none"> • Transmitter Model • Transmitter Supply Voltage • Operating Element • Emergency Stop Switch • Frequency Ranges • Activation Type • Antenna • Battery Type • Battery Voltage/Capacity • Continuous Runtime • Operating Temperature Range • Material of Enclosure • Weight • Dimensions • Protection • Charger Type • Battery charging time • Feedback • LED Feedback • Frequency Management • APCO (Automatic Power cut-off) 	<p>Dove</p> <p>3.6 V</p> <p>10 two-step push buttons + Rotary switch (Optional)</p> <p>Yes</p> <p>433.000-434.775 MHz</p> <p>Button Combination</p> <p>Internal</p> <p>Rechargeable Li battery BLP3055</p> <p>3.6V/3000mAh</p> <p>Approx. 26 hrs.</p> <p>-15 C to 70 C</p> <p>ABS Plastic</p> <p>370 gm</p> <p>W64mm x D56mm x H224mm</p> <p>IP65</p> <p>CLP3055 (AC charger) Suitable for Battery BLP3055</p> <p>Approx. 4 hrs</p> <p>LCD Display, Vibration alarm</p> <p>Operating/Battery Status:</p> <p>Manual Frequency Switching</p> <p>Approx. 5 min after last Input command.</p>

